



BERG PLAYBASE

Assembly instructions

Montage instructies

Montageanleitung


Instructions de montage

Monteringsvejledning

ASSEMBLY




1/2






20.10.00.00




1

2x




2

2x




3

2x




4

4x




5

10x




6

8x




7

8x




8

26x




9

4x




10

4x






20.10.01.00




1

2x




2

2x




3

2x




4

6x




5

10x




6

12x




7

12x




8

34x




9

6x




10

6x







20.11.00.00




12 2x




13 2x




14 2x




15 1x




16 2x




17 2x




5 8x




6 2x




7 2x



18 4x




8 16x




19 4x

20.11.01.00




12

2x




13

2x




14

2x




15

7x




16

2x




17

2x




5

8x




6

14x




7

14x




18

4x



8

40x










19








4x



1




2








3






2x




4




12x




5




13




18 6x




21 4x




22 10x




23 4x




13 2x



14 1x





16 2x




17 2x

6



12 2x





15 1x



7




13



8





2x






15 4x

9





10








11






12









16x










Large




Medium












16










17














Swing height adjustment



EN: Adjusting eight without lip. Ensure that the product hangs horizontal after adjustment of the ropes.

NL: Stelacht zonder lip. Let erop dat het product steeds horizontaal hangt na verstelling van de touwen.


DE: Achterhaken ohne Dorn. Achten Sie darauf, dass das Produkt nach de Höhenverstellung waagerecht hängt.

FR: Huit de réglage sans lame. Faites attention que le produit soit dans une position horizontale après l'ajustement des cordes.

DK: Otte justeringer uden klinge. Sørg for, at produktet hænger vandret efter justering af rebene.



Climbing net installation



EN: Adjusting eight with lip. Ensure that the climbing net ends are smaller than 10 cm after installation.

NL: Stelacht met lip. Zorg ervoor dat de uiteinden van het klimnet na installatie kleiner zijn dan 10 cm.

DE: Achterhaken mit Dorn. Stellen Sie sicher, dass die Kletternetzenden nach der Installation kleiner als 10 cm sind.

FR: Huit de réglage avec lame. Assurez-vous que les extrémités du filet d'escalade sont inférieures à 10 cm après l'installation.

DK: Otte justeringer med klinge. Sørg for, at enderne på klatrenet er mindre end 10 cm efter installationen.



BERGTOYS.COM

B/N sticker